

WOOX

DESIGNED TO PERFORM. BY NATURE.

WILD MAN



MANUAL & INSTALLATION GUIDE

INDEX

| | |
|--------------------------|-------|
| INDEX | p. 2 |
| WOOX HERITAGE | p. 3 |
| PRODUCT OVERVIEW | p. 4 |
| KEY FEATURES | p. 5 |
| SPECIFICATIONS | p. 5 |
| WILD MAN COMPONENTS LIST | p. 6 |
| ASSEMBLY | p. 7 |
| CLEANING AND CARE | p. 8 |
| WARRANTY | p. 9 |
| CONTACT | p. 11 |

WOOX HERITAGE

When it comes to outdoor products and explorer accessories, some are made in a factory by scientists, and others are born on the workshop of an artisan with sawdust under his fingernails.

We are the creation when that artisan builds a lab. Drawing from over 100 years of Italian tradition and cutting-edge global technology, we are driven by a passionate group of enthusiasts who have made it their mission to bring the outdoor industry forward. This is the heritage of WOOX!

We are dedicated to providing advanced products and personal assistance that will transform your adventures – heirlooms to pass down to generations and stories to tell your grandchildren.

This is what we do.

Your Fellow Outdoorsman

A handwritten signature in black ink that reads "Kendall Reep". The signature is written in a cursive, flowing style with a large initial 'K' and 'R'.

Kendall Reep

WILD MAN PRODUCT OVERVIEW

The Wild Man rifle stock integrates groundbreaking technology with a classic look and feel.

This traditional-style rifle stock is perfect for both a new build or for upgrading your favorite hunting rifle. The Wild Man is a sturdy and reliable aftermarket replacement for most major manufacturer's OEM rifle stocks. It is manufactured using only the highest quality parts, materials and techniques.

It pairs an aerospace braided aluminum skeleton to superior wooden front and rear stocks.

The rear stock features an adjustable butt pad giving you an adjustable LOP of 1" or 2.5 cm, with an intuitive construction that makes disassembly and cleaning quick and easy.

Whether starting a new build from the ground up, upgrading, or even replacing an old hunting stock, all are perfect for the Wild Man.

Regardless of the application, the WOOX Wild Man rifle stock brings new technology with a traditional look and feel that is unmatched both on the range or in the great outdoors.

KEY FEATURES

- **CHASSIS:** WOOX milled aerospace aluminum chassis.
- **CONSTRUCTION:** Forged monobloc body.
- **RECOIL:** Vibration reducing hardwood stocks.
- **HERITAGE:** 100 years of experience in rifle stock construction and design.
- **HYBRID CREATION:** Improved traditional rifle stock created from aerospace aluminum chassis and wood furniture.

SPECIFICATIONS

To view the detailed product specifications visit <https://wooxstore.com/products/wild-man-precision-stock>

WILD MAN COMPONENTS LIST

- A. Rear Stock
- B. Butt Pad
- C. Flush Cup / Quick-Detach Sling Swivel
- D. Grip
- E. 5mm Rear Stock Retention Screw
- F. Monobloc Body
- G. Front Stock Assembly
- H. Sling Mounts



ASSEMBLY

Step 1. With the rifle attached to the original stock., turn the rifle upside-down in the rest so the underside of the rifle is facing up.

Step 2. With the bottom of the rifle turned up, remove both forward and rear action retention screws (located at forward and rear of the trigger guard). If you have a base plate, remove it now. The original rifle stock should lift free of the rifle.

Step 3. With the bottom of the rifle turned up, remove both forward and rear action retention screws (located at forward and rear of the trigger guard). If you have a base plate, remove it now. The original rifle stock should lift free of the rifle.

Step 4. Make sure your WOOX rifle stock is properly seated to the rifle.

Step 5. Your rifle should be properly attached to your new WOOX stock. Read all safety materials before operating.

CLEANING AND CARE

1. Remove the rifle from the stock. See installation instructions p. 10.
2. Dampen a cleaning cloth with WOOX cleaning kit degreaser. Clean front to back. Use the WOOX provided vinyl brush to clean any troublesome areas.
3. To clean the front stock assembly, first remove the T25 Torx bit. Also, remove both sling mount screws. Clean all necessary areas.
4. Reassemble in reverse order of disassembly.
5. Clean monobloc housing. Wipe away remaining degreaser.
6. Wipe down the reassembled rifle and stock with a light coat of the rifle manufacturer's recommended gun oil.

WARRANTY

We hope you are happy with your WOOX products. However, if you have experienced problems with your WOOX product, we encourage you to seek information in our FAQ section. You are also welcome to contact our Customer Support if you need assistance to troubleshoot any problems you are experiencing.

IMPORTANT: BY USING YOUR WOOX PRODUCTS BRANDED ITEMS, YOU ARE AGREEING TO BE BOUND BY THE TERMS OF OUR TWO-YEAR LIMITED WARRANTY (“WARRANTY”) AS SET OUT BELOW.

Limited Hardware Warranty

Subject to the limitations set forth below, WOOX, LLC. (“WOOX”) warrants that its products will be free from defects in materials and workmanship, under normal use and service for two years from the date of purchase from WOOX or its authorized resellers.

You may return any new hardware product purchased from WOOX that arrives in damaged condition, for a full refund within 30 days of purchase. WOOX reserves the right to test these damaged returns and impose a customer fee equal to 15 percent of the product sales price if the customer misrepresents the condition of the product. Any returned product that is damaged through customer Any replaced or repaired product or part has a ninety (90) day warranty or the remainder of the initial warranty period, whichever is longer. This warranty does not apply to equipment that has been damaged or rendered defective,

- as a result of accident, misuse or abuse;
- by the use of parts not manufactured or sold by WOOX;
- by modification without prior written consent from WOOX;
- damage resulting from transit, neglect, power surge or failure, or operating environment;
- any event not due to normal wear and tear; or for -
- discontinued items;

WARRANTY

- periodic inspections for maintenance;
- failure of the product arising from incorrect installation or use not consistent with the instructions and technical or safety standards prescribed in the product user manual; or
- failure of any item as a result of not following the proper care instructions provided in the product user manual.

This limited warranty only applies to the original purchaser of the WOOX product with original proof of purchase.

Warranty and return service may be obtained by contacting WOOX Support within the applicable warranty period for a Return Material Authorization (RMA) number. Once an RMA number is issued, the defective product must be shipped back to WOOX prepaid, insured and wrapped in the original or similar shipping package to ensure that it will not be damaged during shipment. When returning defective product to WOX for service, the RMA number must be marked on the outside of the shipping package. Any product received at WOOX not packaged properly may be refused as out of warranty. Physically damaged products due to improper packaging will not be processed for warranty.

Any product returned without an RMA number may be rejected and sent back to the Customer at WOOX' discretion. WOOX disclaims any obligation to pay for the shipping of any such returned product, it being understood that the Customer shall bear the cost of returning such products.

This limited warranty gives you specific legal rights and does not, in any way, affect the rights given to you by law.

WOOXSTORE.COM



@WOOXOUTDOOR

WOOX LLC

1245 26th Street SE, Hickory, NC 28602 - USA

Registered[®] and Trademarked[™] in 2019. All rights reserved.